

IVL Carre/Pyramide Avolites Device File :

Please find attached the Avolite personality and a show file for the IVL Fixtures, in Mode 1 + Mode 2.

You can clone the same fixtures that are in the patch if you need to add more fixtures to the show.

You will find some Color, Position and Gobo/Beam presets.

Attention: in the Gobo/Beam presets, you will find 4 pages.

Page 1: corresponds to the size of the beam.

Page 2: presets for 2 or 4 beams (a group of presets for slow to fast rotation, Clock-Wise to Counter-Clock-Wise)

Page 3: Presets for 8 or 16 beams.

Page 4: Presets for 32 or 64 beams.

It is important to determine the size of the beam first, otherwise, you won't see the number of beams or the rotation effect.

In general, when you choose an IVL Lighting fixture or a group of IVL fixtures, you can press the 'attribute editor' tab to open the control for each mirror and each RGB beam control options.

That way you can easily control each tilt of the fixture or each color for the beam possibilities.